# INSTALLATION


### Attention: the installation and the out of service of the instrument must be done by skilled personnel only.

The installation of gas and the possible stopping device must be in according to the national and in force prescriptions law.

### DETECTOR POSITIONING

## The instrument have to be installed:

- the 992 M for methane should be fixed at a maximum distance of 30 cm from the ceiling.
- the 992 G for LPG should be fixed at a maximum distance of 30 cm from the floor.
- They should be fixed at a distance comprises from 1 meter and 4 meters by the gas device (kitchen, boiler room, etc...)
- Possibly in every room in which there is a gas device and, in the residences with more that one floor, at least one for each floor.



## Avoid installing:

Directly over the sink or the gas device in little locals where can be utilised alcohol, ammonia, spray bottles of gas or other substances with flying solvents.

In low ventilated environments or near to walls or obstacles that can stop the gas flow from the user to the detector, or near to exhausters or fans that can divert the air flow.


In environment in which the temperature can arrive over 40°C or under –10°C.

In environment with a lot of humidity or vapours.

## INSTALLATION PROCEDURES

By using an screwdriver unscrew on the right hand side the instrument and uncover it.

The box cover has to be positioned on the three form point or on the wall, by using the screws and plugs available.



# ELECTRICAL CONNECTION

## POWER SUPPLY

Attention: the electrical connection has to be done with an under track cable. The gas detector 992 have to be powered at 230Vac by the terminals 1 and 2 It has to be provided with an device, to be disowned from the detector and the feeding net, as written in the European Standard EN 60335-1.



#### CHARACTERISTICS OF THE EXIT-SIGNAL

The detector 992 is provided with an external relay with free tension contacts, capacity of connection 3(1)A 250Vac / 2A 24Vcc.

### ELECTRO-VALVES CONNECTION

The gas detector 992 has inside a jumper that permits to select the type of electro-valve to connect that can be Normally Opened type or Normally Closed type.

We remind that the valve should be installed on the gas pipes outside the room under control, since protection is useless if a gas leak occurs at the beginning of the gas pipe.




**Positioning N.O.**: proper for normally opened valves


Positioning N.C.: proper for normally closed valves or for the contemporaneously check of both electrovalve and an external electrical charge.

# GAS LEAK DETECTOR

# INSTALLATION







### PERIODICAL TESTING

We recommend to contact the installer at least once a year for a general verification IMPORTANT: Do not use pure gas, such as a lighter, directly on the sensor since the sensor could be irremediably damaged.

#### OPERATIONAL CHECK

After the installation it is possible to check the correct operational of the instrument by pushing for at least 2 seconds the TEST button on the board, in this way all the leds will be alight, the acoustic alarm and the relay will be on for 5 second. At this point it will be necessary to rearm the electro valve connected.

#### <u>WARNING</u>

For the cleaning, use an cloth on the top. Not be opened, it could cause damage.

Note that the sensor employed has a good resistance towards products such as sprays, detergents, alcohol, glues and paints.

However, these products could contain substances which, if in great quantity, could interfere with the sensor and cause false alarms.

We recommend to ventilate the room should products like these be used.

Note that the detector is not able to detect gas leaks occurring outside the room where it is installed, neither inside walls nor under the floor.

To make gas (methane and LPG) nose identifiable, gas is added with a particularly disturbing smelling substance.

Small gas quantities coming out from left open cookers for some minutes do not cause the gas detector alarm signalling even if it is clearly nose perceptible; in fact the quantity of gas presents in the environment can be under the alarm threshold.

Please remember that the gas detector cannot work without power supply.

#### WARNING!! In case of alarm:

1) Extinguish all naked flames

2) Turn off the gas supply at the gas emergency control and/or, with a LPG supply, the storage tank

3) Do not switch on or off any electrical lights. Do not activate any electrically powered devices4) Open both doors and windows to increase room ventilation

If the alarm stops, it is necessary to identify the alarm reason and act accordingly

If the alarm condition continues and the cause of the leak is not apparent and/or cannot be corrected, vacate the premises and immediately notify the gas emergency service.